



# TransFlex Cover Sheet

**A TRANSPARENT TRANSFER TAPE FOR USE WITH TRANSFLEX OPACITY, TRANSFLEX OPACITY PUFF, AND TRANSFLEX METALLIC, WHICH ARE PRINTED WITH SOLVENT OR ECO-SOLVENT BASED PRINTERS**

## **Application:**

- The Transflex Cover Sheet is to be used with the transflex polyurethane films, as the films are extremely thin and require an aggressive adhesive to adequately peel from the carrier paper.
- Allow the printed image to dry up to 60 minutes on any of the Transflex films.
- After weeding the excess film off of the carrier paper, apply the Transflex Cover Sheet over the image, and make sure to use a squeegee to eliminate any air bubbles between the transfer tape and the printed film. Pierce the air bubble with an X-Acto knife or the weeder, if necessary, and use the squeegee to deflate the air bubble.

**NOTE:** Since the adhesive on the Transflex Cover Sheet is very strong, and corrections are extremely difficult to make, we recommend starting with a tiny piece of the Transflex Cover Sheet over a small area.

- Lift the image off of the carrier paper by peeling the Transflex Cover Sheet.
- Place the Transflex Cover Sheet on the fabric, image facing up, and position the image as desired.
- Place the Kraft Paper onto the Transflex Cover Sheet for protection. A silicone sheet can also be used.
- Press for recommended time, using temperature suggested for the Transflex Film being used.
- Peel off the Transflex Cover Sheet when hot. If transferring onto a repellent fabric, peel slowly when cold.
- Once again, place the Kraft Paper onto the image, and transfer using the recommended time and temperature for the Transflex Film being used.

**IMPORTANT:** Please keep your 1 Step® Transflex Cover Sheet in the plastic bag until actual use. This will prevent the accumulation of dust particles. Close the bag after each use.